

# Panel Indikator PM 1430 & PM 1530



## Catalogue

<b>1. Reading Before Use</b> .....	<b>1</b>
<b>2. Warranty</b> .....	<b>2</b>
2.1 Warranty for New Product .....	2
2.2 Warranty Under Maintenance .....	2
2.3 Service Network .....	3
<b>3. Product Introduction</b> .....	<b>4</b>
<b>4. Order Information</b> .....	<b>5</b>
<b>5. Specification</b> .....	<b>6</b>
<b>6. Operation Element</b> .....	<b>8</b>
<b>7. Button Symbols</b> .....	<b>9</b>
<b>8. Terminal Assignment</b> .....	<b>12</b>
<b>9. Dimension</b> .....	<b>14</b>
<b>10. Program Commands</b> .....	<b>15</b>
<b>11. Program Settings Flowchart</b> .....	<b>20</b>
<b>12. Operation Procedure</b> .....	<b>21</b>
<b>11. Non-Linearity Measurement Settings</b> .....	<b>32</b>
11.1 Non-Linearity Measuring Software Introduction .....	33
<b>12. Communication</b> .....	<b>34</b>
12.1 ModBus Command List .....	34
12.2 Communication Parameter .....	35
<b>13. Product Application and Program Setting Examples</b> .....	<b>38</b>
13.1 Current Input Wiring .....	38
13.2 Program Setting Example 1 .....	39
13.3 Program Setting Example 2 .....	40
13.4 Program Setting Example 3 .....	40
<b>14. Trouble Shooting and Notice Examples</b> .....	<b>42</b>
14.1 Fault Finding and Repair .....	42
14.2 Installation Notice .....	43
14.3 7-Segment Display Corresponding To The Codes .....	43
14.4 Forgot User Code .....	44
14.5 Loop Resistance Range .....	44

## 1. Reading Before Use

Thank you for your purchase for FineTek product. This menu introduces the product features, operations, maintenance and troubleshooting to help user get familiar with product, and avoid harm by unperoper use. Before use, please carefully study the details of product. Extra support requirement can be found at [www.fine-tek.com](http://www.fine-tek.com) or directly contact us by telephone and facsimile. On line revision will issue at web site and not further inform. User can get newest support and download at [www.fine-tek.com](http://www.fine-tek.com). In case of any unexpected problem, don't disassemble it by yourself or you will lose the product guarantee. Contact us, if you have any question hard to be defined.

### Symbol Instruction



**Danger**→ Deathly danger or significant harm might be caused with unproper use.



**Notice**→ Damage to user or equipment with unproper use.



**Electric Shock**→ Notice for Electric Shock.



**Fire**→ Notice for Fire.



**Prohibit**→ Prohibit for Wrong Operation.

## 2. Warranty

### 2.1 Warranty for New Product

All FineTek products will get one year guarantee in regular operation. Product within guarantee period will get service and no charge for any nominal fee. User finds any defect during delivery process or not be broken by wrong operation that can ask return or replace. In maintenance, user has the obligation to send all complete parts to FineTek in well carefully package. Over range operation, over charge or any abnormal operation will excess out the guarantee range. Product not in guarantee period and condition will charge necessary fee for the repair or replace.

Things below will not in guarantee coverage and will be charged service fee:

- Expire the guarantee date.
- Not properly use according to operation manual.
- Irresistible environment effects or natural disaster (earthquake, flood disaster, fire, lighting stroke, hurricane)
- Human-made damage (scratch, cutting, throwing down, hammering) or abnormal operation (over power range, over ambient condition, over range operation, corrosion, watering, electric charge), non-proved third-party device connection or expend, replace non-proved components or module.

### 2.2 Warranty Under Maintenance

Maintenance Guarantee: All the products will get six months guarantee service since repair or replaced components. During six months, any fault caused in same condition will be serviced with free charge

### 2.3 Service Network

Beanch	Address	Tel	Fax
<b>Head Quarter (Taiwan)</b>	No.16, Tzuchiang St., Tucheng Industrial Park, New Taipei City 236, Taiwan	+886 2-2269-6789	+886 2-2268-6682
<b>Taichung Brance (Taiwan)</b>		+886 4-2465-2820	+886 4-2463-9926
<b>Kaoshung Branch (Taiwan)</b>		+886 7-333-6968	+886 7-536-8758
<b>Fineautomation Co.,Ltd. (China)</b>	No.451 DuHui Rd, MinHang District, Shanghai, China 201109	+86 216490-7260	+86 216490-7276
<b>Beijing Branch Office (China)</b>	No.8 GuanGqu Men Street, Block A, Room 191	+86 108353-5118	+86 108353-2816
<b>Guangzhou Branch Office (China)</b>	No.536 LongKou Rd West, Grass Park B-18C TianHe District, Guangzhou, China	+86 203846-1387	+86 203846-1397
<b>Wuhan Branch Office(China)</b>	No.14 ZhongZan Rd, Century square , Block B, WuChang District, Wuhan, China	+86 27-8733-2314	+86 27-8733-2341
<b>Jinan Branch Office (China)</b>	No.44 HongLou Rd South, HuiKe Park Building 6, Unit 2, Room 1601, LicHeng District, Jinan, China	+86 531-83173652	+86 31-83173670
<b>Nanjing Branch (China)</b>	Everest Building Room 1709, 19 Cutral Road, Nanjing Drum Tower District, Nanjing, China	+86 025-83176832	+86 025-83176831
<b>Finetek Pte Ltd. (Singapore)</b>	No. 11 Kaki Bukit Road 1 #04-01 Eunos Technolink 415939, Singapore	+65 6452-6340	+65 6734-1878
<b>FineTeK GmbH (Germany)</b>	Frankfurter Str. 62, OG D-65428 Ruesselsehim, Germany	+49 (0)6142-17608-16	+49 (0)142-17608-20

### 3. Product Introduction

PM-1430 (4 digits display) and PM-1530 (5 digits display) are digital type microprocessor panel meters, which accept various signal inputs. Digital numeric can be set as any unit display, for examples kg/cm<sup>2</sup>, bar, cm and kg...etc. It is suitable for most process and electrical measurements.

#### Feature

- a. 4 push buttons control panel, user friendly.
- b. Wide power supply range 20~250 Vac/Vdc.
- c. Readings range -1999~9999 (4 digits) & -19999~99999 (5 digits).
- d. Available with one current or voltage input, and one voltage or current output.
- e. Variable inputs acceptable as 0~20mA, 4~20mA, 0~200 mA, 0~5V, 1~5V, 0~10V, 2~10V, 0~20V, 0~200V inputs, and also be applied with non-standard input signal range, for example used with Capacitance Level Transmitter.
- f. Two loop power supply 24 Vdc/50mA to drive measuring instrument.
- g. Available with 1~4 relays output, and 1 set DI ( digital in ) for relay driver.
- h. Sampling time is 24 t/seconds, against miscellaneous signal interference.
- i. Available with RS-485 ModBus interface.
- j. Non linearity measurement is available with all panel meters, to improve linearity for non-regular shaped silo / tank.




## 5. Specification

Item	Specification	Remark
<b>Power Supply</b>	20 ~250Vac-Vdc · 50 / 60Hz	
<b>Power Consumption</b>	7 VA (MAX)	
<b>Operation Temp.</b>	-20~70 °C , 20%~90% RH non-condensed	
<b>Storage Temp.</b>	-20~75 °C , 20%~90% RH non-condensed	
<b>Display</b>	0.56" 4 digits 7 segment LED display Readings range: -1999 ~ 9999 0.56" 5 digits 7 segment LED display Readings range:-19999 ~ 99999 4 LED set-point indicator Over range display: "1 " or "-1"	
<b>Accuracy</b>	Input signal (AD) : DC— $\pm 0.1\%$ F.S. , AC— $\pm 1\%$ F.S. TC— $\pm 0.5\%$ F.S. , RTD— $\pm 1\%$ F.S. Output signal(DA) : $\pm 0.5\%$ full scale	SIM-D02&D03, SIM-D04, SIM-D05: $\pm 0.2\%$ F.S
<b>Sampling Time</b>	Standard model: 24 times / second	
<b>Input Signal</b>	<b>SIM-100&amp;200:</b> 0~20mAdc, 4~20mAdc, 0~200mAdc, 0~5Vdc, 1~5Vdc, 0~10Vdc, 2~10Vdc, 0~20Vdc, 0~200Vdc. <b>SIM-A01:</b> 0~2mAac, 0~20mAac, 0~200mAac. SIM-A02 & A03: 0~1Aac, 0~5Aac ◦ <b>SIM-A05:</b> 0~100mVac, 0~200mVac, 0~2Vac. <b>SIM-A06:</b> 0~20Vac, 0~200Vac, 0~600Vac, 0~1000 Vac. <b>SIM-D01:</b> 0~ $\pm 2$ mAdc, 0~ $\pm 20$ mAdc, 0~ $\pm 200$ mAdc.	







<p><b>Input Signal</b></p>	<p><b>SIM-D02&amp; D03:</b> 0~±1Adc, 0~±5Adc.</p> <p><b>SIM-D04:</b> 0~5/10/20/50/100/200mVdc ◦ Isolated Exciting 5Vdc — 1mV/V, 2mV/V, 4mV/V, 10mV/V, 20mV/V, 40mV/V ◦ Isolated Exciting 10Vdc — 1mV/V, 2mV/V, 5mV/V, 10mV/V, 20mV/V ◦</p> <p><b>SIM-D05:</b> 0~±20mVdc, 0~±50mVdc, 0~±100mVdc,0~±200mVdc ◦</p> <p><b>SIM-D06:</b> TC (K·J·R·S·B·E·N·T) &amp; RTD (PT100·JPT100) ◦ K: -200 ~ 1370°C J: -200 ~ 1200°C E: -200 ~ 800°C N: -200 ~1300°C T: -200 ~ 400°C R: 0 ~ 1760°C (500 ~ 1760°C is available range) S: 0 ~ 1760°C (500 ~ 1760°C is available range) B: 0 ~ 1820°C (800 ~ 1820°C is available range) PT100: -200 ~ 850°C JPT100: -200 ~ 500°C</p>	
<p><b>Output Signal</b></p>	<p>0~20mAdc,4~20mAdc,20~0mAdc,20~4mAdc, 0~5Vdc, 1~5Vdc, 0~10Vdc, 2~10Vdc ◦</p>	
<p><b>Relay Output</b></p>	<p>4 relay: SPDT 3A / 250V AC or 5A / 30V DC</p>	
<p><b>Digital Input</b></p>	<p>1 Digital In</p>	<p>Option</p>
<p><b>Communication Interface</b></p>	<p>RS 485 Modbus</p>	<p>Option</p>
<p><b>Memory</b></p>	<p>By EEPROM</p>	
<p><b>Dimension</b></p>	<p>DIN 1/8 :96 mm × 48 mm×128.5mm</p>	
<p><b>Enclosure Protection</b></p>	<p>IP65 rating</p>	

## 6. Operation Element



## 7. Button Symbols

Set up all functions by the 4 push buttons on the panel (ENT · SHT · UP and DOWN). Firstly enter the selection menu, then set required value of 4 push buttons while in „Selection” and „Setting”:

Item	Selection	Settings
	Switch	Save Data
	Enter	Position Shift
	Escape	Increase
	Escape	Decrease

### ENTER Button


To help you to identify selection and setting modes, please follow the operation charts below:

Introduction: (UP and DOWN is the same in selection mode. However UP means increase, and DOWN means decrease in setting mode.

### ENRER Button


Main menu switch or sub-menu switch




Example: STEP1~ STEP2 and STEP3~ STEP5



Confirmation to save settings

Example: Confirmation of change of SCHi value.




-  /  : Modify Parameter
-  : Save Parameter Setting

### ◀ SHIFT Button

Entry from main menu to sub-menu, or position change in sub-menu.

For example: STEP 1 and STEP 2, STEP 3~7.




SHIFT: Entry into modification mode, press SHIFT to move to the numeric to be modified.

For example, to modify SCHi value – One numeric flashes, and press SHIFT to select the numeric which you want to change setting.

### ^ UP Button


To escape from main menu, or escape from sub-menu to move to main menu.

For example: STEP 1 and STEP 2





Pressure UP button to increase the numeric.


For example: To change SCHi value from “1230” to “1234”, press UP button four times at the last digit “0” to “4”.





<b>SIM-A06</b>	VIN+ 17 18 19 20 21 VIN-
<b>SIM-D01</b>	EXC EXC +24V GND AIN- AIN+ 17 18 19 20 21
<b>SIM-D02&amp;D03</b>	EXC EXC +24V GND AIN- AIN+ 17 18 19 20 21
<b>SIM-D04</b>	EXC EXC +24V GND VIN- VIN+ 17 18 19 20 21
<b>SIM-D05</b>	EXC EXC +24V GND VIN- VIN+ 17 18 19 20 21
<b>SIM-D06</b>	TC- TC+ RTD 17 18 19 20 21
<b>Thermocouple (TC):</b>	
	
<b>Resistance Temperature Detectors (RTD) :</b>	
	

### 9. Dimension



(Unit: mm)



## 10. Program Commands

Command	Description	4 Digits Setting Range	4 Digits Factory Default	5 Digits Setting Range	5 Digits Factory Default
PASS	Password	0~9999	4607	0~9999	4607
CHSL	Channel Selection	CH1/CH2	CH1	CH1/CH2	CH1
SETT	Settings Selection for TEMP , TYPE , UNIT				
TEMP	Room Temp. Display Function	ON/OFF	OFF	The fifth digit is the unit temperature	
TYPE	Temperature Type Selection	K、J、T、E、R、 S、B、N、PT	K	The fifth digit is the unit temperature	
UNIT	Temperature Unit Display	°C/°F	°C	The fifth digit is the unit temperature	
SCAL	Settings Selection for DCPT , SCH , SCL				
DCPT	Decimal Point Selection	0~3	Dot1	0~4	Dot2
SCH	Display Value for SPAN	-1999~9999	100.0	-19999~99999	100.00
SCL	Display Value for ZERO	-1999~9999	000.0	-19999~99999	000.00
SETP	Settings Selection for FULL , SP1~SP4 , HON1~HON4 , DON1~DON4 , DOF1~DOF4 , ENB1~ENB4 , ALR1~ALR4				
FULL	STEP Entire Function / Simple Function Switch	YES/NO	NO	YES/NO	NO
SP1	SP1 Set Point Value	-1999~9999	020.0	-19999~99999	020.00
SP2	SP2 Set Point Value	-1999~9999	040.0	-19999~99999	040.00
SP3	SP3 Set Point Value	-1999~9999	060.0	-19999~99999	060.00
SP4	SP4 Set Point Value	-1999~9999	080.0	-19999~99999	080.00
HON1	SP1 Hysterises High Band	0~9999	000.0	0~99999	000.0
HON2	SP2 Hysterises High Band	0~9999	000.0	0~99999	000.0
HON3	SP3 Hysterises High Band	0~9999	000.0	0~99999	000.0
HON4	SP4 Hysterises High Band	0~9999	000.0	0~99999	000.0
HOF1	SP1 Hysterises Low Band	0~9999	000.0	0~99999	000.0
HOF2	SP2 Hysterises Low Band	0~9999	000.0	0~99999	000.0
HOF3	SP3 Hysterises Low Band	0~9999	000.0	0~99999	000.0
HOF4	SP4 Hysterises Low Band	0~9999	000.0	0~99999	000.0
DON1	SP1 Relay Response Delay Time (in seconds)	00~99	00	00~99	00

# Användarmanual

## PM 1430 & PM 1530



www.wallox.se

DON2	SP2 Relay Response Delay Time (in seconds)	00~99	00	00~99	00
DON3	SP3 Relay Response Delay Time (in seconds)	00~99	00	00~99	00
DON4	SP4 Relay Response Delay Time (in seconds)	00~99	00	00~99	00
DOF1	SP1 Relay Response Reversion Delay Time (in seconds)	00~99	00	00~99	000
DOF2	SP2 Relay Response Reversion Delay Time (in seconds)	00~99	00	00~99	00
DOF3	SP3 Relay Response Reversion Delay Time (in seconds)	00~99	00	00~99	00
DOF4	SP4 Relay Response Reversion Delay Time (in seconds)	00~99	00	00~99	00
ENB1	SP1 Relay On/Off Selection	ON/OFF	ON	ON/OFF	ON
ENB2	SP2 Relay On/Off Selection	ON/OFF	ON	ON/OFF	ON
ENB3	SP3 Relay On/Off Selection	ON/OFF	ON	ON/OFF	ON
ENB4	SP4 Relay On/Off Selection	ON/OFF	ON	ON/OFF	ON
ALR1	SP1 Hi/Lo Alarm Selection	HI/LO	LO	HI/LO	LO
ALR2	SP2 Hi/Lo Alarm Selection	HI/LO	LO	HI/LO	LO
ALR3	SP3 Hi/Lo Alarm Selection	HI/LO	HI	HI/LO	HI
ALR4	SP4 Hi/Lo Alarm Selection	HI/LO	HI	HI/LO	HI
INP	Settings Selection for ISEL , SCHi , SCLi				
ISEL	Input S ignal S election: 0~20 , 4~20 , 200I , 0~5 , 1~5 , 0~10 , 2~10 , 20V , 200V , SPE		4~20		4~20
SCHi	SPAN Percentage for SPE Mode	0~1000	100.0	0~10000	100.00
SCLi	ZERO Percentage for SPE Mode	0 ~1000	000.0	0~10000	000.00
out	Setting for SIG				

# Användarmanual

## PM 1430 & PM 1530



www.wallox.se

Sig	Output Signal Selection: 0~20 , 4~20 , 20~0 , 20~4 , 0~10 , 2~10 , 0~5 , 1~5 , SPE		4~20		4~20
DIRY	Settings Selection for SRY , RY1 , RY2 , RY3 , RY4				
SRY	DI Function	ON/OFF	OFF	ON/OFF	OFF
RY1	Relay 1 Activation Prohibited	ON/OFF	OFF	ON/OFF	OFF
RY2	Relay 2 Activation Prohibited	ON/OFF	OFF	ON/OFF	OFF
RY3	Relay 3 Activation Prohibited	ON/OFF	OFF	ON/OFF	OFF
RY4	Relay 4 Activation Prohibited	ON/OFF	OFF	ON/OFF	OFF
RATE	Settings Selection for FILT , adSEL				
FILT	Anti-miscellaneous signals feature	ON/OFF	ON	ON/OFF	ON
adSEL	AD24 reading rate Anti-miscellaneous signal filter OFF: 24 times/ second Anti-miscellaneous signal filter ON: 4 times/ second AD12 reading rate Anti-miscellaneous signal filter OFF: 12 times/ second Anti-miscellaneous signal filter ON: 2 times/ second AD06 reading rate Anti-miscellaneous signal filter OFF: 6 times/ second Anti-miscellaneous signal filter ON: 1 time/ second		AD24 , AD12 , AD06		AD24 , AD12 , AD06
LOCU	Setting for LOPE				
LOPE	Reduce 0~99% Input Signal	0~99	0	0~99	0
NOLI	Non-Linear Tank Function				
SEL	Enable/Disable	ON/OFF	OFF	ON/OFF	OFF
LP1	Silo / Tank Set Point # 1	0~1000	5	0~10000	5
LP2	Silo / Tank Set Point # 2	0~1000	10	0~10000	10
LP3	Silo / Tank Set Point # 3	0~1000	15	0~10000	15
LP4	Silo / Tank Set Point # 4	0~1000	20	0~10000	20
LP5	Silo / Tank Set Point # 5	0~1000	25	0~10000	25
LP6	Silo / Tank Set Point # 6	0~1000	30	0~10000	30

# Användarmanual

## PM 1430 & PM 1530



www.wallox.se

LP7	Silo / Tank Set Point # 7	0~1000	35	0~10000	35
LP8	Silo / Tank Set Point # 8	0~1000	40	0~10000	40
LP9	Silo / Tank Set Point # 9	0~1000	45	0~10000	45
LP10	Silo / Tank Set Point # 10	0~1000	50	0~10000	50
LP11	Silo / Tank Set Point # 11	0~1000	55	0~10000	55
LP12	Silo / Tank Set Point # 12	0~1000	60	0~10000	60
LP13	Silo / Tank Set Point # 13	0~1000	65	0~10000	65
LP14	Silo / Tank Set Point # 14	0~1000	70	0~10000	70
LP15	Silo / Tank Set Point # 15	0~1000	75	0~10000	75
LP16	Silo / Tank Set Point # 16	0~1000	80	0~10000	80
LP17	Silo / Tank Set Point # 17	0~1000	85	0~10000	85
LP18	Silo / Tank Set Point # 18	0~1000	90	0~10000	90
LP19	Silo / Tank Set Point # 19	0~1000	95	0~19999	95
LP20	Silo / Tank Set Point # 20	0~1000	100	0~10000	100
IV1	Input Signal Set Point # 1	0~1000	5	0~10000	5
IV2	Input Signal Set Point # 2	0~1000	10	0~10000	10
IV3	Input Signal Set Point # 3	0~1000	15	0~10000	15
IV4	Input Signal Set Point # 4	0~1000	20	0~10000	20
IV5	Input Signal Set Point # 5	0~1000	25	0~10000	25
IV6	Input Signal Set Point # 6	0~1000	30	0~10000	30
IV7	Input Signal Set Point # 7	0~1000	35	0~10000	35
IV8	Input Signal Set Point # 8	0~1000	40	0~10000	40
IV9	Input Signal Set Point # 9	0~1000	45	0~10000	45
IV10	Input Signal Set Point # 10	0~1000	50	0~10000	50
IV11	Input Signal Set Point # 11	0~1000	55	0~10000	55
IV12	Input Signal Set Point # 12	0~1000	60	0~10000	60
IV13	Input Signal Set Point # 13	0~1000	65	0~10000	65
IV14	Input Signal Set Point # 14	0~1000	70	0~10000	70
IV15	Input Signal Set Point # 15	0~1000	75	0~10000	75
IV16	Input Signal Set Point # 16	0~1000	80	0~10000	80
IV17	Input Signal Set Point # 17	0~1000	85	0~10000	85
IV18	Input Signal Set Point # 18	0~1000	90	0~10000	90
IV19	Input Signal Set Point # 19	0~1000	95	0~10000	95
IV20	Input Signal Set Point # 20	0~1000	100	0~10000	100
cod	User Code Modification	0~9999	4607	4607	0~9999
SYS	Settings Selection for LOAD · FINE				

# Användarmanual

## PM 1430 & PM 1530




www.wallox.se

LOAD	Reset to Default Setting	YES/NO	NO	YES/NO	NO
FINE	Read Software Version Code				










Command	Description	Setting Range	Factory Default
CONN	RS485 Transmission Setting		
IDNO	Set ModBus Communication Address	0~255	255
BPS	Set ModBus Transmission Rate (Baud Rate)	more	9600
600	600 Baud	600	
1200	1200 Baud	1200	
2400	2400 Baud	2400	
4800	4800 Baud	4800	
9600	9600 Baud	9600	
144G	14400 Baud	14400	
192G	19200 Baud	19200	
STYL	Set Transmission Style	more	8N1
8N1	8 Byte, No Parity, 1 Stop Bit	8N1	
8N2	8 Byte, No Parity, 2 Stop Bits	8N2	
8O1	8 Byte, Odd Parity, 1 Stop Bit	8O1	
8E1	8 Byte, Even Parity, 1 Stop Bit	8E1	
FORN	Set Transmission Mode	more	HEX
HEX	RTU Mode	HEX	
ASCI	ASCII Mode	ASCII	
TOUT	Time Out	100~9999mS	300mS










## 11. Program Settings Flowchart

- Only available for PM-2430, choose CH 1 or CH 2.
- SETT is only available with TC & RTD module, and SCAL is not available.
- \* Non-linearity function and input settings are optional.














## 12. Operation Procedure

Step	Function	Symbols Display	Note
1.	Please make sure product specification and wirings are correct, then operate the controller via 20~250Vac/Vdc power source.		PM-1530-W example
2.	Start up logo: FINE		
	Software version: A-01 as indicated		
	Entry to monitoring screen: Indication without any setting		If INP is 4-20mA 、 1-5V 、 2-10V, indication will be -25.00.
<b>Device Parameter Protected by User Code</b>			
3.	3-1 Press <b>ENT</b> key under monitoring screen 、 and password is required for entry. The controller indicates PASS/no.	 	
	3-2 Press <b>SHT</b> key 、 and the numeric flashes. Adjust the numeric by <b>Up</b> 、 <b>Down</b> key. Then you can press <b>SHT</b> key to switch to another numeric position.		User code default is 4607. Indicated number is user code +1234.
	3-3 After setting is completed, press <b>ENT</b> key to save data. Now the device indicates PASS/YES.	 	
<b>SETT : Settings for TEMP 、 TYPE 、 UNIT</b>			
4.	4-1 Press <b>ENT</b> key for entry, and select "SETT" mode.		













<p>4-2</p> <p>Press <b>SHT</b> key for entry, and press <b>SHT</b> key again. The indicator "TEMP" flashes quickly. Use <b>Up</b> \ <b>Down</b> key select the sub-menu, and press <b>ENT</b> key after selection.</p>	  	<p>TEMP is display for indoor temperature. (Default is non-display for indoor temperature.)</p>
<p>4-3</p> <p>Press <b>ENT</b> key, and select "TYPE" mode, which shows current setting. Press <b>SHT</b> key for entry, and use <b>UP</b>, <b>DOWN</b> to adjust setting. Press <b>ENT</b> key to save data.</p>	  	<p>TTYPE is for temperature selections - K \ J \ T \ E \ R \ S \ B \ N \ PT types. (Default is K type). When you use K \ J \ T \ E \ R \ S \ B \ N types, please set INP value as 0-20. For PT type, INP value has to be 200I.</p>
<p>4-4</p> <p>Press <b>ENT</b> key, and choose "UNIT" mode which shows current setting. Press <b>SHT</b> key for entry, and use <b>UP</b>, <b>DOWN</b> to adjust setting. Press <b>ENT</b> key to save data.</p>	  	<p>UNIT is temperature unit selection for °C or °F (Default is °C)</p>



SCAL : Settings for DCPT , SCH , SCL		
5-1 Press <b>ENT</b> key, and select "SCAL" mode.		
5-2 Press <b>SHT</b> key for entry to "DCPT". Press <b>SHT</b> key again, the numeric on the indicator starts to flash quickly. Use <b>Up</b> - <b>Down</b> key to adjust the setting, and press <b>ENT</b> key to save data after setting.	  	Dot setting range is 0~4.
5. 5-3 Press <b>SHT</b> key to enter full scale setting "SCH". The indicator starts to flash quickly. Use <b>Up</b> - <b>Down</b> key to adjust the setting, and press <b>ENT</b> key to save data after setting.	  	SCH setting range is -19999~99999.
5-4 Press <b>SHT</b> key to enter zero scale setting "SCL". The indicator starts to flash quickly. Use <b>Up</b> - <b>Down</b> key to adjust the setting, and press <b>ENT</b> key to save data after setting.	  	SCL setting range is -19999~99999.
SETP : Settings for FULL , SP , HON , HOF , DON , DOF , ENB , ALR		
6. 6-1 Press <b>ENT</b> key, and select "SETP" mode.		FULL setting OFF: SP1~SP4→ALR1~ALR4 FULL setting ON:













# Användarmanual

## PM 1430 & PM 1530

<p>6-2</p> <p>Press <b>ENT</b> key, the indicator "FULL" flashes quickly and shows current setting. Press <b>SHT</b> key for entry, and use <b>UP</b>, <b>DOWN</b> to adjust setting. Press <b>ENT</b> key to save data.</p>	  	<p>SP1~SP4</p> <p>→HON1~HON4</p> <p>→HOF1~HOF4</p> <p>→DON1~DON4</p> <p>→DOF1~DOF4</p> <p>→ENB1~ENB4</p> <p>→ALR1~ALR4</p>
<p>6-3</p> <p>Press <b>SHT</b> key, and enter to SP1~SP4 relay contact settings. Use <b>Up</b> · <b>Down</b> key to select the numeric, then press <b>SHT</b> key to switch numeric position. Use <b>Up</b> · <b>Down</b> to adjust numeric setting. Press <b>ENT</b> key to save data.</p>	 <p style="text-align: center;">\</p> 	<p>SP1~SP4</p> <p>Relay contact setting</p> <p>range : -19999~99999</p>
<p>6-4</p> <p>Press <b>SHT</b> key to enter HON1~HON4 hysteresis high band setting. Use <b>Up</b> · <b>Down</b> key to select the numeric, then use <b>SHT</b> key to switch numeric position. Use <b>Up</b> · <b>Down</b> key to adjust numeric setting and press <b>ENT</b> key to save data.</p>	  	<p>HON1~HON6</p> <p>Hysteresis high band setting range: 0~99999</p>
<p>6-5</p> <p>Press <b>SHT</b> key to enter HOF1~HOF4 hysteresis low band setting. Use <b>Up</b> · <b>Down</b> key to select the numeric, then use <b>SHT</b> key to switch numeric position. Use <b>Up</b> · <b>Down</b> key to adjust numeric setting and press <b>ENT</b> key to save data.</p>	  	<p>HOF1~HOF6</p> <p>Hysteresis low band setting range: 0~99999</p>
<p>6-6</p> <p>Press <b>SHT</b> key to enter DON1~DON4 relay response delay setting. Use <b>Up</b> · <b>Down</b> key to select the numeric, then use <b>SHT</b> key to switch numeric position. Use <b>Up</b> ·</p>		<p>DON1~DON4</p> <p>Relay response delay setting: 0~99 seconds</p>













# Användarmanual













## PM 1430 & PM 1530












	<p>Down key to adjust numeric setting and pressure ENT key to save data.</p>	 	
	<p>6-7 Press SHT key to enter DOF1~DOF4 relay response reversion delay setting. Use Up · Down key to select the numeric, then use SHT key to switch numeric position. Use Up · Down key to adjust numeric setting and pressure ENT key to save data.</p>	  	<p>DOF1~DOF4 Relay response reversion delay setting: 0~99 seconds</p>
	<p>6-8 Press SHT key to enter relay on/off setting "ENB". The indicator starts to flash quickly. Use Up · Down key to adjust relay setting on/off, and press ENT key to save data after setting.</p>	  	<p>ENB1~ENB4 Relay setting selection: ON / OFF</p>
	<p>6-9 Press SHT key to enter high/low alarm setting "ALR". The indicator starts to flash quickly. Use Up · Down key to adjust alarm setting on/off, and press ENT key to save data after setting.</p>	  	<p>ALR1~ALR4: High /low alarm selection: HI / LO</p>
	<b>INP : Settings for ISEL · SCHI · SCLI</b>		
7.	<p>7-1 Press ENT key and select "INP" mode.</p>		













# Användarmanual













## PM 1430 & PM 1530

<p>7-2</p> <p>Press <b>SHT</b> key to enter input type selection "iSEL". The indicator starts to flash quickly. Use <b>Up</b> / <b>Down</b> key to select input type, and press <b>ENT</b> key to save data after selection.</p>	  	<p>Input type selection:          0-20(mA) \ 4-20(mA) \ 200I(mA) \ 0-5(V) \ 1-5(V) \ 0-10(V) \ 2-10(V) \ 20V(V) \ 200V(V) \ SPE</p>
<p>7-3</p> <p>Press <b>ENT</b> key, and select "SCHi" mode.</p>	 	<p>Input type selection:          0-20(mA) \ 4-20(mA) \ 200I(mA) \ 0-5(V) \ 1-5(V) \ 0-10(V) \ 2-10(V) \ 20V(V)</p> <p>Be displayed on indicator.</p>
<p>7-4</p> <p>Press <b>ENT</b> key, and select "SCLi" mode.</p>	 	<p>Input type selection:          0-20(mA) \ 4-20(mA) \ 200I(mA) \ 0-5(V) \ 1-5(V) \ 0-10(V) \ 2-10(V) \ 20V(V)</p> <p>Be displayed on indicator.</p>
<p>7-5</p> <p>Press <b>SHT</b> key and the indicator "iSEL" starts to flash quickly. Use <b>Up</b> / <b>Down</b> key to select sub-menu, and press <b>ENT</b> key to save data after selection.</p>	  	<p>Input type selection:          0-20(mA) \ 4-20(mA) \ 200I(mA) \ 0-5(V) \ 1-5(V) \ 0-10(V) \ 2-10(V) \ 20V(V) \ 200V(V) \ SPE</p>
<p>7-6</p> <p>Press <b>SHT</b> key, and select "SCHi" mode which flashes quickly. Use <b>Up</b> / <b>Down</b> key to set value.</p> <p>Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> / <b>Down</b> key to set value.</p>	 	<p>Input type "SPE" selected:</p> <p>Full scale setting:          000.00~100.00</p>













	<p>Press <b>ENT</b> key to save data after setting.</p>		
	<p>7-7</p> <p>Press <b>SHT</b> key, and select "SCLi" mode which flashes quickly. Use <b>Up</b> · <b>Down</b> key to set value.</p> <p>Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value.</p> <p>Press <b>ENT</b> key to save data after setting.</p>	  	<p>Input type "SPE" selected:</p> <p>Empty scale setting: 000.00~100.00</p>
<b>OUT : Setting for SIG</b>			
	<p>8-1</p> <p>Press <b>ENT</b> key, and select "OUT" mode.</p>		
8.	<p>8-2</p> <p>Press <b>SHT</b> key for entry. Press <b>SHT</b> key again, and the indicator "SIG" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>Output type selection: 0-20(mA) · 4-20(mA) · 20-0(mA) · 20-4(mA) · 0-5(V) · 1-5(V) · 0-10(V) · 2-10(V)</p>
<b>DIRY : Settings for SRY · RY1 · RY2 · RY3 · RY4</b>			
	<p>9-1</p> <p>Press <b>ENT</b> key, and select "DIRY" mode.</p>		
9.	<p>9-2</p> <p>Press <b>SHT</b> key for entry. Press <b>SHT</b> key again, and the indicator "SRY" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>DI: Operation allowed or prohibited: OFF / ON</p>

	<p>9-3</p> <p>Press <b>SHT</b> key, the indicator "RY" flashes quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>RY1~RY4</p> <p>Relay activation prohibited / allowed selection: OFF / ON</p>
<b>RATE : Settings for FILT · AD24 · AD12 · AD06</b>			
	<p>10-1</p> <p>Press <b>ENT</b> key, and select "RATE" mode.</p>		
10.	<p>10-2</p> <p>Press <b>SHT</b> key for entry. Press <b>SHT</b> key again, and the indicator "FILT" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>FILT:</p> <p>Anti-miscellaneous signals feature</p> <p>OFF / ON</p>
	<p>10-3</p> <p>Press <b>SHT</b> key, the indicator "RTAD" flashes quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>AD24 · AD12 · AD06:</p> <p>3 Reading speed selectable</p>
<b>LOCU : Setting for LOPE</b>			
11.	<p>11-1</p> <p>Press <b>ENT</b> key, and select "LOCU" mode.</p>		<p>LOPE:</p> <p>Low input signal reduction: 0~99%</p>

	<p>11-2</p> <p>Press <b>SHT</b> key for entry. Press <b>SHT</b> key again, and the indicator “LOPE” starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	
<b>NOLI : Setting for non-linearity measurement</b>			
	<p>12-1</p> <p>Press <b>ENT</b> key, and select “NOLI” mode.</p>		
	<p>12-2</p> <p>Press <b>SHT</b> key for entry. Press <b>SHT</b> key again, and the indicator “SEL” starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	 	
<p>12.</p>	<p>12-3</p> <p>Press <b>SHT</b> key to enter dimension settings for LP1~LP20 non-linearity silo/tank measurement. Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value. Press <b>ENT</b> key to save data after setting.</p>	  	<p>LP1~LP20</p> <p>Non-linearity silo/tank measurement dimension setting range:</p> <p>000.00~100.00</p>
	<p>12-4</p> <p>Press <b>SHT</b> key to enter input settings for IV1~IV20 non-linearity silo/tank measurement. Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value. Press <b>ENT</b> key to save data after setting.</p>	  	<p>IV1~IV20</p> <p>Non-linearity silo/tank measurement input setting range:</p> <p>000.00~100.00</p>
<p>13.</p>	<b>User Code Modification</b>		

	<p>13-1</p> <p>Press <b>SHT</b> key to enter user code setting "Cod". Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value. Press <b>ENT</b> key to save data after setting.</p>	  	
<b>SYS : Setting for LOAD · FINE</b>			
	<p>14-1</p> <p>Press <b>ENT</b> key, and select "SYS" mode.</p>		
14.	<p>14-2</p> <p>Press <b>SHT</b> key for entry, and the indicator "LOAD" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	 	<p>LOAD:</p> <p>Reset to Default Setting</p> <p>NO / YES</p>
	<p>14-3</p> <p>Press <b>ENT</b> key, and select "FINE" mode.</p>	 	<p>FINE:</p> <p>Company name and software version identification</p>
<b>Conn : Setting for RS485 Communication</b>			
	<p>15-1</p> <p>Press <b>ENT</b> key, and select "CONN" mode.</p>		
15.	<p>15-2</p> <p>Press <b>SHT</b> key to enter ModBus communication address setting "IDNO". Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value. Press <b>ENT</b> key to save data after setting.</p>	  	<p>ModBus:</p> <p>Communication address setting range:</p> <p>00001~00255</p>



<p>15-3</p> <p>Press <b>SHT</b> key for entry, and the indicator "BPS" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>ModBus transmission rate (baud rate) selectable :</p> <ul style="list-style-type: none"> <li>600(600BPS) ·</li> <li>1200(1200BPS) ·</li> <li>2400(2400BPS) ·</li> <li>4800(4800BPS) ·</li> <li>9600(9600BPS) ·</li> <li>1440(14400BPS) ·</li> <li>1920(19200BPS) ·</li> </ul>
<p>15-4</p> <p>Press <b>SHT</b> key for entry, and the indicator "STYL" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>Data transmission style selection:</p> <ul style="list-style-type: none"> <li>8N1(8 Byte, No parity, 1 Stop Bit) ·</li> <li>8N2(8 Byte, No parity, 2 Stop Bit) ·</li> <li>8O1(8 Byte, Odd parity, 1 Stop Bit) ·</li> <li>8E1 (8 Byte, Even parity, 1 Stop Bit)</li> </ul>
<p>15-5</p> <p>Press <b>SHT</b> key for entry, and the indicator "ASCI" starts to flash quickly. Use <b>Up</b> · <b>Down</b> key to select sub-menu. Press <b>ENT</b> key to save data.</p>	  	<p>Data transmission mode selection:</p> <ul style="list-style-type: none"> <li>HEX (RTU Mode) ·</li> <li>ASCI (ASCII Mode)</li> </ul>
<p>15-5</p> <p>Press <b>SHT</b> key to enter time out setting "TOUT". Press <b>SHT</b> key to switch numeric position, and use <b>Up</b> · <b>Down</b> key to set value. Press <b>ENT</b> key to save data after setting.</p>	  	<p>Time out setting range: 100~9999 (ms)</p>




## 11. Non-Linearity Measurement Settings

Features:

Non-linearity measurement is suitable for non-regular shaped tanks, to provide more accurate measurement than traditional device.

Configuration:

Linearization of input signals and calculated values of 20 points (LP1~LP20). Input signals can be divided into 20 points (IV1~IV20), and calculate the proportional value accordingly.




Example: Enter silo/tank height and the number of 20 setting points into the parameters of this device.


### 11.1 Non-Linearity Measuring Software Introduction

Get into "Vessel Master" for setting into the software.

This software has two languages versions for your choices – Chinese & English.  
Setting → Language → Chinese, or Setting → Language → English.



There are 11 kinds of non-regular silo / tank shapes for your choices. Please enter the numbers of height, width, length of your silo / tank. Then press  to save data.



You can print out the 20 setting points – File => Print.

## 12. Communication

### 12.1 ModBus Command List

Panel Meter ModBus Command List														
Address	Function	Authority	Address	Function	Authority	Address	Function	Authority	Address	Function	Authority	Address	Function	Authority
0	VerCode	R												
1	Sp1_HB	R/W	51	Don3	R/W	101	Ch1Lp09	R/W	151	DspData2H	R	201	Ch2IV19	R/W
2	Sp1_LB	R/W	52	Don4	R/W	102	Ch1Lp10	R/W	152	DspData2L	R	202	Ch2IV20	R/W
3	Sp2_HB	R/W	53	Don5	R/W	103	Ch1Lp11	R/W	153	Ch2Dot	R/W	203	Ch2SRY	R/W
4	Sp2_LB	R/W	54	Don6	R/W	104	Ch1Lp12	R/W	154	Ch2SchH	R/W	204	Ry5	R/W
5	Sp3_HB	R/W	55	Don7	R/W	105	Ch1Lp13	R/W	155	Ch2SchL	R/W	205	Ry6	R/W
6	Sp3_LB	R/W	56	Don8	R/W	106	Ch1Lp14	R/W	156	Ch2SchH	R/W	206	Ry7	R/W
7	Sp4_HB	R/W	57	Dof1	R/W	107	Ch1Lp15	R/W	157	Ch2SchL	R/W	207	Ry8	R/W
8	Sp4_LB	R/W	58	Dof2	R/W	108	Ch1Lp16	R/W	158	Ch2Sel	R/W	208	Ch2FIL T	R/W
9	Sp5_HB	R/W	59	Dof3	R/W	109	Ch1Lp17	R/W	159	Ch2Schi	R/W	209	Ch2RTAD	R/W
10	Sp5_LB	R/W	60	Dof4	R/W	110	Ch1Lp18	R/W	160	Ch2Scli	R/W	210	Ch2LOCU	R/W
11	Sp6_HB	R/W	61	Dof5	R/W	111	Ch1Lp19	R/W	161	Ch2Out	R/W	211		
12	Sp6_LB	R/W	62	Dof6	R/W	112	Ch1Lp20	R/W	162	Ch2Sel	R/W	212		
13	Sp7_HB	R/W	63	Dof7	R/W	113	Ch1IV01	R/W	163	Ch2Lp01	R/W	213		
14	Sp7_LB	R/W	64	Dof8	R/W	114	Ch1IV02	R/W	164	Ch2Lp02	R/W	214		
15	Sp8_HB	R/W	65	Ehb1	R/W	115	Ch1IV03	R/W	165	Ch2Lp03	R/W	215		
16	Sp8_LB	R/W	66	Ehb2	R/W	116	Ch1IV04	R/W	166	Ch2Lp04	R/W	216		
17	Hon1_HB	R/W	67	Ehb3	R/W	117	Ch1IV05	R/W	167	Ch2Lp05	R/W	217		
18	Hon1_LB	R/W	68	Ehb4	R/W	118	Ch1IV06	R/W	168	Ch2Lp06	R/W	218		
19	Hon2_HB	R/W	69	Ehb5	R/W	119	Ch1IV07	R/W	169	Ch2Lp07	R/W	219		
20	Hon2_LB	R/W	70	Ehb6	R/W	120	Ch1IV08	R/W	170	Ch2Lp08	R/W	220		
21	Hon3_HB	R/W	71	Ehb7	R/W	121	Ch1IV09	R/W	171	Ch2Lp09	R/W	221		
22	Hon3_LB	R/W	72	Ehb8	R/W	122	Ch1IV10	R/W	172	Ch2Lp10	R/W	222		
23	Hon4_HB	R/W	73	Ahr1	R/W	123	Ch1IV11	R/W	173	Ch2Lp11	R/W	223		
24	Hon4_LB	R/W	74	Ahr2	R/W	124	Ch1IV12	R/W	174	Ch2Lp12	R/W	224		
25	Hon5_HB	R/W	75	Ahr3	R/W	125	Ch1IV13	R/W	175	Ch2Lp13	R/W	225		
26	Hon5_LB	R/W	76	Ahr4	R/W	126	Ch1IV14	R/W	176	Ch2Lp14	R/W	226		
27	Hon6_HB	R/W	77	Ahr5	R/W	127	Ch1IV15	R/W	177	Ch2Lp15	R/W	227		
28	Hon6_LB	R/W	78	Ahr6	R/W	128	Ch1IV16	R/W	178	Ch2Lp16	R/W	228		
29	Hon7_HB	R/W	79	Ahr7	R/W	129	Ch1IV17	R/W	179	Ch2Lp17	R/W	229		
30	Hon7_LB	R/W	80	Ahr8	R/W	130	Ch1IV18	R/W	180	Ch2Lp18	R/W	230		
31	Hon8_HB	R/W	81	DspData1H	R	131	Ch1IV19	R/W	181	Ch2Lp19	R/W	231		
32	Hon8_LB	R/W	82	DspData1L	R	132	Ch1IV20	R/W	182	Ch2Lp20	R/W	232		
33	Hof1_HB	R/W	83	Ch1Dot	R/W	133	Ch1SRY	R/W	183	Ch2IV01	R/W	233		
34	Hof1_LB	R/W	84	Ch1SchH	R/W	134	Ry1	R/W	184	Ch2IV02	R/W	234		
35	Hof2_HB	R/W	85	Ch1SchL	R/W	135	Ry2	R/W	185	Ch2IV03	R/W	235		
36	Hof2_LB	R/W	86	Ch1SchH	R/W	136	Ry3	R/W	186	Ch2IV04	R/W	236		
37	Hof3_HB	R/W	87	Ch1SchL	R/W	137	Ry4	R/W	187	Ch2IV05	R/W	237		
38	Hof3_LB	R/W	88	Ch1Sel	R/W	138	Ch1FIL T	R/W	188	Ch2IV06	R/W	238		
39	Hof4_HB	R/W	89	Ch1Schi	R/W	139	Ch1RTAD	R/W	189	Ch2IV07	R/W	239		
40	Hof4_LB	R/W	90	Ch1Schi	R/W	140	Ch1LOCU	R/W	190	Ch2IV08	R/W	240		
41	Hof5_HB	R/W	91	Ch1Out	R/W	141			191	Ch2IV09	R/W	241		
42	Hof5_LB	R/W	92	Ch1Sel	R/W	142			192	Ch2IV10	R/W	242		
43	Hof6_HB	R/W	93	Ch1Lp01	R/W	143			193	Ch2IV11	R/W	243		
44	Hof6_LB	R/W	94	Ch1Lp02	R/W	144			194	Ch2IV12	R/W	244		
45	Hof7_HB	R/W	95	Ch1Lp03	R/W	145			195	Ch2IV13	R/W	245		
46	Hof7_LB	R/W	96	Ch1Lp04	R/W	146			196	Ch2IV14	R/W	246		
47	Hof8_HB	R/W	97	Ch1Lp05	R/W	147			197	Ch2IV15	R/W	247		
48	Hof8_LB	R/W	98	Ch1Lp06	R/W	148			198	Ch2IV16	R/W	248		
49	Dom1	R/W	99	Ch1Lp07	R/W	149			199	Ch2IV17	R/W	249		
50	Dom2	R/W	100	Ch1Lp08	R/W	150			200	Ch2IV18	R/W	250		

### 12.2 Communication Parameter

Address	VerCode	Function	Authority
00 H			
01 H	Sp1H	SP1 Set point value, High setting ranges: -1 ~ 9	R/W
02 H	Sp1L	SP1 Set point value, Low setting ranges: -1999 ~ 9999	R/W
03 H	Sp2H	SP2 Set point value, High setting ranges: -1 ~ 9	R/W
04 H	Sp2L	SP2 Set point value, Low setting ranges: -1999 ~ 9999	R/W
05 H	Sp3H	SP3 Set point value, High setting ranges: -1 ~ 9	R/W
06 H	Sp3L	SP3 Set point value, Low setting ranges: -1999 ~ 9999	R/W
07 H	Sp4H	SP4 Set point value, High setting ranges: -1 ~ 9	R/W
08 H	Sp4L	SP4 Set point value, Low setting ranges: -1999 ~ 9999	R/W
09 H	Sp5H	SP5 Set point value, High setting ranges: -1 ~ 9	R/W
10 H	Sp5L	SP5 Set point value, Low setting ranges: -1999 ~ 9999	R/W
11 H	Sp6H	SP6 Set point value, High setting ranges: -1 ~ 9	R/W
12 H	Sp6L	SP6 Set point value, Low setting ranges: -1999 ~ 9999	R/W
13 H	Sp7H	SP7 Set point value, High setting ranges: -1 ~ 9	R/W
14 H	Sp7L	SP7 Set point value, Low setting ranges: -1999 ~ 9999	R/W
15 H	Sp8H	SP8 Set point value, High setting ranges: -1 ~ 9	R/W
16 H	Sp8L	SP8 Set point value, Low setting ranges: -1999 ~ 9999	R/W
17 H	Hon1H	SP1 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
18 H	Hon1L	SP1 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
19 H	Hon2H	SP2 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
20 H	Hon2L	SP2 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
21 H	Hon3H	SP3 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
22 H	Hon3L	SP3 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
23 H	Hon4H	SP4 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
24 H	Hon4L	SP4 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
25 H	Hon5H	SP5 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
26 H	Hon5L	SP5 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
27 H	Hon6H	SP6 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
28 H	Hon6L	SP6 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
29 H	Hon7H	SP7 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
30 H	Hon7L	SP7 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
31 H	Hon8H	SP8 Hysterises High Band, High setting ranges: 0 ~ 9	R/W
32 H	Hon8L	SP8 Hysterises High Band, Low setting ranges: 0 ~ 9999	R/W
33 H	Hof1H	SP1 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
34 H	Hof1L	SP1 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
35 H	Hof2H	SP2 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
36 H	Hof2L	SP2 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
37 H	Hof3H	SP3 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
38 H	Hof3L	SP3 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
39 H	Hof4H	SP4 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
40 H	Hof4L	SP4 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
41 H	Hof5H	SP5 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
42 H	Hof5L	SP5 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
43 H	Hof6H	SP6 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
44 H	Hof6L	SP6 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
45 H	Hof7H	SP7 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
46 H	Hof7L	SP7 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W
47 H	Hof8H	SP8 Hysterises Low Band, High setting ranges: 0 ~ 9	R/W
48 H	Hof8L	SP8 Hysterises Low Band, Low setting ranges: 0 ~ 9999	R/W

# Användarmanual

## PM 1430 & PM 1530



www.wallox.se

49H	Don1	SP1 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
50H	Don2	SP2 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
51H	Don3	SP3 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
52H	Don4	SP4 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
53H	Don5	SP5 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
54H	Don6	SP6 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
55H	Don7	SP7 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
56H	Don8	SP8 Relay Response Delay Time, Setting ranges: 0 ~ 99	R/W
57H	Dof1	SP1 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
58H	Dof2	SP2 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
59H	Dof3	SP3 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
60H	Dof4	SP4 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
61H	Dof5	SP5 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
62H	Dof6	SP6 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
63H	Dof7	SP7 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
64H	Dof8	SP8 Relay Response Reversion Delay Time, Setting ranges: 0 ~ 99	R/W
65H	Enb1	SP1 Relay On (1) /Off (0) Selection	R/W
66H	Enb2	SP2 Relay On (1) /Off (0) Selection	R/W
67H	Enb3	SP3 Relay On (1) /Off (0) Selection	R/W
68H	Enb4	SP4 Relay On (1) /Off (0) Selection	R/W
69H	Enb5	SP5 Relay On (1) /Off (0) Selection	R/W
70H	Enb6	SP6 Relay On (1) /Off (0) Selection	R/W
71H	Enb7	SP7 Relay On (1) /Off (0) Selection	R/W
72H	Enb8	SP8 Relay On (1) /Off (0) Selection	R/W
73H	Alr1	SP1 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
74H	Alr2	SP2 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
75H	Alr3	SP3 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
76H	Alr4	SP4 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
77H	Alr5	SP5 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
78H	Alr6	SP6 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
79H	Alr7	SP7 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
80H	Alr8	SP8 Hi( 1 ) / Lo( 0 ) Alarm Selection	R/W
81H	DspData1H	The First Decimal Display (-1~9)	R
82H	DspData1L	The Second ~ FiFth Decimal Display (-1999~9999)	R
83H	Ch1Dot	Decimal point setting range: 0 ~ 4	R/W
84H	Ch1SchH	Full scale setting, the first decimal setting (-1~9)	R/W
85H	Ch1SchL	Full scale setting, second ~ fifth decimal setting (-1999~9999)	R/W
86H	Ch1SciH	Zore scale setting, the first decimal setting (-1~9)	R/W
87H	Ch1ScL	Zore scale setting, second ~ fifth decimal setting (-1999~9999)	R/W
88H	Ch1IseL	Input signal selections : 0~20( 0 ) , 4~20( 1 ) , 200I( 2 ) , 0~5( 3 ) , 1~5( 4 ) , 0~10( 5 ) , 2~10( 6 ) , 20V( 7 ) , 200V( 8 ) , SPE( 9 )	R/W
89H	Ch1Schi	Full scale setting under IESL/SPE mode: 4 decimal setting 0~1000 , 5 decimal setting 0~10000	R/W
90H	Ch1ScLi	Zero scale setting under IESL/SPE mode: 4 decimal setting 0~1000 , 5 decimal setting 0~10000	R/W
91H	Ch1Out	Output signal selection: 0~20( 0 ) , 4~20( 1 ) , 20~0( 2 ) , 20~4( 3 ) , 0~5( 4 ) , 1~5( 5 ) , 0~10( 6 ) , 2~10( 7 )	R/W
92H	Ch1Sel	Non-linearity measurement On ( 1 ) or Off ( 0 )	R/W
93H	Ch1Lp01	Silo/Tank setting point 1: 4 decimal 0~1000, 5 decimal 0~10000	R/W
94H	Ch1Lp02	Silo/Tank setting point 2: 4 decimal 0~1000, 5 decimal 0~10000	R/W
95H	Ch1Lp03	Silo/Tank setting point 3: 4 decimal 0~1000, 5 decimal 0~10000	R/W
96H	Ch1Lp04	Silo/Tank setting point 4: 4 decimal 0~1000, 5 decimal 0~10000	R/W
97H	Ch1Lp05	Silo/Tank setting point 5: 4 decimal 0~1000, 5 decimal 0~10000	R/W
98H	Ch1Lp06	Silo/Tank setting point 6: 4 decimal 0~1000, 5 decimal 0~10000	R/W
99H	Ch1Lp07	Silo/Tank setting point 7: 4 decimal 0~1000, 5 decimal 0~10000	R/W

# Användarmanual

## PM 1430 & PM 1530




www.wallox.se

100H	Ch1Lp08	Silo/Tank setting point 8: 4 decimal 0~1000, 5 decimal 0~10000	R/W
101H	Ch1Lp09	Silo/Tank setting point 9: 4 decimal 0~1000, 5 decimal 0~10000	R/W
102H	Ch1Lp10	Silo/Tank setting point 10: 4 decimal 0~1000, 5 decimal 0~10000	R/W
103H	Ch1Lp11	Silo/Tank setting point 11: 4 decimal 0~1000, 5 decimal 0~10000	R/W
104H	Ch1Lp12	Silo/Tank setting point 12: 4 decimal 0~1000, 5 decimal 0~10000	R/W
105H	Ch1Lp13	Silo/Tank setting point 13: 4 decimal 0~1000, 5 decimal 0~10000	R/W
106H	Ch1Lp14	Silo/Tank setting point 14: 4 decimal 0~1000, 5 decimal 0~10000	R/W
107H	Ch1Lp15	Silo/Tank setting point 15: 4 decimal 0~1000, 5 decimal 0~10000	R/W
108H	Ch1Lp16	Silo/Tank setting point 16: 4 decimal 0~1000, 5 decimal 0~10000	R/W
109H	Ch1Lp17	Silo/Tank setting point 17: 4 decimal 0~1000, 5 decimal 0~10000	R/W
110H	Ch1Lp18	Silo/Tank setting point 18: 4 decimal 0~1000, 5 decimal 0~10000	R/W
111H	Ch1Lp19	Silo/Tank setting point 19: 4 decimal 0~1000, 5 decimal 0~10000	R/W
112H	Ch1Lp20	Silo/Tank setting point 20: 4 decimal 0~1000, 5 decimal 0~10000	R/W
113H	Ch1IV01	Input signal setting point 1: 4 decimal 0~1000, 5 decimal 0~10000	R/W
114H	Ch1IV02	Input signal setting point 2: 4 decimal 0~1000, 5 decimal 0~10000	R/W
115H	Ch1IV03	Input signal setting point 3: 4 decimal 0~1000, 5 decimal 0~10000	R/W
116H	Ch1IV04	Input signal setting point 4: 4 decimal 0~1000, 5 decimal 0~10000	R/W
117H	Ch1IV05	Input signal setting point 5: 4 decimal 0~1000, 5 decimal 0~10000	R/W
118H	Ch1IV06	Input signal setting point 6: 4 decimal 0~1000, 5 decimal 0~10000	R/W
119H	Ch1IV07	Input signal setting point 7: 4 decimal 0~1000, 5 decimal 0~10000	R/W
120H	Ch1IV08	Input signal setting point 8: 4 decimal 0~1000, 5 decimal 0~10000	R/W
121H	Ch1IV09	Input signal setting point 9: 4 decimal 0~1000, 5 decimal 0~10000	R/W
122H	Ch1IV10	Input signal setting point 10: 4 decimal 0~1000, 5 decimal 0~10000	R/W
123H	Ch1IV11	Input signal setting point 11: 4 decimal 0~1000, 5 decimal 0~10000	R/W
124H	Ch1IV12	Input signal setting point 12: 4 decimal 0~1000, 5 decimal 0~10000	R/W
125H	Ch1IV13	Input signal setting point 13: 4 decimal 0~1000, 5 decimal 0~10000	R/W
126H	Ch1IV14	Input signal setting point 14: 4 decimal 0~1000, 5 decimal 0~10000	R/W
127H	Ch1IV15	Input signal setting point 15: 4 decimal 0~1000, 5 decimal 0~10000	R/W
128H	Ch1IV16	Input signal setting point 16: 4 decimal 0~1000, 5 decimal 0~10000	R/W
129H	Ch1IV17	Input signal setting point 17: 4 decimal 0~1000, 5 decimal 0~10000	R/W
130H	Ch1IV18	Input signal setting point 18: 4 decimal 0~1000, 5 decimal 0~10000	R/W
131H	Ch1IV19	Input signal setting point 19: 4 decimal 0~1000, 5 decimal 0~10000	R/W
132H	Ch1IV20	Input signal setting point 20: 4 decimal 0~1000, 5 decimal 0~10000	R/W
138H	Ch1FILT	Anti-miscellaneous signals feature On ( 1 ) / Off ( 0 )	R/W
139H	Ch1RTAD	AD reading rate selection AD06( 0 ) · AD12( 1 ) · AD24( 2 )	R/W
140H	Ch1LOCU	Input signal cut-off setting, rang: 0~99(%)	R/W


## 13. Product Application and Program Setting Examples

### 13.1 Current Input Wiring

#### a. 2-wire Input signal 4~20mA




#### b. 4-wire Input signal 4~20mA





### 13.2 Program Setting Example 1

Magnetic Float Level Transmitter provides current output 4~20mA for liquid level from empty to full tank. The transmitter can be applied with PM-1530-W Panel Meter.



#### Application and Settings:

Empty tank, current output 4mA, display 000.00

Full tank, current output 20mA, display 100.00

Relay 1 (SP1) setting point at 20% of tank level --- low level alarm

Relay 2 (SP2) setting point at 40% of tank level --- low level alarm


Relay 3 (SP3) setting point at 60% of tank level --- high level alarm

Relay 4 (SP4) setting point at 80% of tank level --- high level alarm

#### Linearity output signal:

Empty tank: current output 4mA; Full tank: current output 20mA

#### Settings:



### 13.3 Program Setting Example 2

To address the problem with non-standard current input signal 4~20mA, "SPE" mode can help you to make settings easily with the Panel Meter.

Example: Input signal 7mA~11mA, display required as 0%~100% .

Formula:


$$\text{Setting Number} = \frac{\text{Real Current Input}}{\text{SCAL Number Selected by SIM Signal}} \times 100\%$$

Setting:

Current input 7mA~11mA

$$\text{SCLi} = \frac{7}{20} \times 100\% = 35\%$$

$$\text{SCHi} = \frac{11}{20} \times 100\% = 55\%$$





### 13.4 Program Setting Example 3

Settings:


SCH=100.0 S CL=000.0 S P1=020.0 H ON1=005.0 H OF1=010.0

DON=03 DO F=02 E NB1=ON A LR1=Hi





Relay action diagram:








Examples:

- DON=3 means relay response delay time 3 seconds. When analog output is higher than 25 and continues for 3 seconds, SP1 Relay becomes ON.
- DOF=2 means relay response delay time 2 seconds. At timing of 13 seconds, when analog output is lower than 10 and continues for 2 seconds, SP1 Relay becomes OFF.
- DON=3 means relay response delay time 3 seconds. At timing of 18 seconds, when analog output is higher than 25 and continues for 3 seconds, SP1 Relay becomes ON.

## 14. Trouble Shooting and Notice Examples

### 14.1 Fault Finding and Repair

Cause	Cure
No display on panel	<ol style="list-style-type: none"> <li>Please check if power supply is connected.</li> <li>Power supply should be 20~250V AC/DC 50/60Hz.</li> </ol>
Relay failure – no response	<ol style="list-style-type: none"> <li>Please check if LED indication is normal.</li> <li>Check if terminal wiring is connected correctly.</li> </ol>
No display on panel LED indication & Relay failure	<ol style="list-style-type: none"> <li>Check operation menu:                     <div style="text-align: center;">  <p>“Enb” should be ON.</p> </div> </li> <li>“Hon / HoF” should have setting values.                     <div style="text-align: center;">  </div> </li> <li>“Don / DoF” should have setting values.                     <div style="text-align: center;">  </div> </li> <li>“Alf” setting value should be the same as default value.                     <div style="text-align: center;">  </div> </li> </ol>
Discrepancy between analog input and panel display	<p>Check operation menu, and check if settings are correct:</p> <div style="text-align: center;">  </div>
Display does not change even analog input is different.	Check if input signal wiring is connected well.

### 14.2 Installation Notice

#### a. Attention

- Please use the device via correct power source.
- Please keep away from dangerous place with flammable air or fire.
- Please make sure terminal wirings correct.
- Luck screws on terminals tightly.

#### b. Installation Notice – More Care For The Following Place

- With strong vibration or impact
- Ambient temperature & humidity higher than the device's resistance
- Too much dust
- Corrosive air ( especially for sulfur or ammonia )
- Outdoor with sunlight direct explore
- With high frequency equipment nearby ( high frequency welding machinery etc )

#### c. Operation Notice

- Do not use the device in the place with ambient temperature & humidity higher than the device's resistance. The device's life time is related ambient temperature. Ambient temperature becomes higher, that shortens life time.
- If you place several panel meters closely, that will increase temperature inside these meters. Please consider to use cooling device to reduce operation temperature, such as cooling fan.
- Please use relays within the contact rating. Over contact rating will damage the relays.

### 14.3 7-Segment Display Corresponding To The Codes

A: 8	B: b	C: C	D: d	E: E
F: F	G: 9	H: H	I: i	J: J
K: K	L: L	M: E	N: n	O: o
P: P	Q: 9	R: r	S: S	T: t
U: U	V: U	W: 3	X: H	Y: 9
Z: 2				

### 14.4 Forgot User Code

- a. When password is positive number:  
PM-1530-W default password is 4607. When display indicates 5841, please deduct 1234 and you can get the password.
- b. When password is positive number:  
If you deduct number 1234 but get positive number on display, please add 1000 to get positive number. That number is password.

### 14.5 Loop Resistance Range

PM-1530-W loop resistance range is 0 ~ 500Ω. Accuracy will decrease with over resistance (DA >±0.5% F.S.). Please use the device with within this range.